

# Perimeter View™

## PVW1 Wireless Camera Pairing Guide

1. Press and hold monitor [**Power**] button for 3 seconds to power on monitor. Wait for monitor to turn on.
  2. Press and hold [**Pairing**] button on the monitor. The monitor will begin 30 second countdown.
- *Step 3 must be completed during 30 second countdown*
  - *Repeat step 2 if countdown ends before completing step 3.*



# Perimeter View™

## PVW1 Wireless Camera Pairing Guide

3. Move metal button to top hole on back of camera. Screw the button in. The LED near camera lens will repeatedly flash amber/red/amber/red. Repeat step 2 if step 3 is not completed during 30 second count-down.

4. Move the metal button to the bottom hole on back of camera. Screw the button in.

5. Confirm monitor displays camera view.



# Perimeter View™

## PVW1 Examples



**NOT Paired**



No picture on monitor. LED on camera is red.



**Paired**



Monitor displays picture. LED on camera is amber.